

4. With the AP-WRC4 base unit turned on, press the white button on the receiver circuit board and look for the red LED to turn **OFF** (see Figure 2 for button and LED location). A small flat blade screwdriver may be of assistance to press the button in.
5. Once the red LED is off, press any button on the new fob and watch to see that the red LED flashes a couple of times and then turns on.
6. The fob is now programmed to the AP-WRC4 base unit, so check that all the buttons work by pressing each one and looking for the blue light of the AP-WRC4 base unit to flash in response.
7. Repeat steps 3 to 6 for any other fobs that need to be registered.
8. Once finished registering all fobs, put the cover back on the AP-WRC4 base unit and tighten all 4 screws.